

SWAGING MANDRELS FOR 4200-SERIE FITTINGS

9015-00



| Product info | To control that the swaging has resulted in the right internal collapse. GO-side should pass through the fitting to make sure that the swaging is not overdone. |
|---------------|---|
| Product info2 | The STOP-side should stop in the middle of the tail to ensure that the swaging is sufficient. |
| Product group | 900 |
| Туре | Machine accessories |

1/4"

| Part no. | Dimension | |
|----------|--------------|---------|
| 90150305 | 3/16"-5/16" | |
| 90150003 | 3/16" | |
| 90150004 | 1/4" | |
| 90150005 | 5/16" | |
| 90150006 | 3/8" | |
| 90150008 | 1/2" | |
| 90150010 | 5/8" | |
| 90150012 | 3/4" | |
| 90150016 | 1" | |
| 90150020 | 1 1/4" | |
| 90150024 | 1 1/2" | |
| 90150032 | 2" | |
| 90150320 | Complete set | 3/16" - |